


TYPICAL WIRING DIAGRAM



NOTE: Terminals 38, 39, 40 & 41 are not fitted to the DSE7310 MKII.

NOTE: A larger version of the Typical Wiring Diagram is available in the product's operator manual, refer to DSE Publication: 057-253 DSE7310 MKII & DSE7320 MKII Operator Manual available from www.deepseaelectronics.com for more information.

Deep Sea Electronics Ltd.
 Tel: +44 (0)1723 890099
 Email: support@deepseaelectronics.com
 Web: www.deepseaelectronics.com

Deep Sea Electronics Inc.
 Tel: +1 (815) 316 8706
 Fax: +1 (815) 316 8708
 Email: support@deepseausa.com
 Web: www.deepseausa.com

DEEP SEA ELECTRONICS
DSE7310 MKII & DSE7320 MKII
Installation Instructions

053-181
 ISSUE 7

ACCESSING THE MAIN CONFIGURATION EDITOR

- Ensure the engine is at rest and the module is in STOP mode by pressing the (Stop/Reset) button.
 - Press the (Stop/Reset) and (Tick) buttons simultaneously.
 - If a module security PIN has been set, the PIN number request is then shown:
- Editor

Enter Pin

###
- The first '#' changes to '0'. Press the (Up) or (Down) button to adjust it to the correct value.
 - Press the (Right) button when the first digit is correctly entered. The digit previously entered now shows '#' for security.
 - Repeat this process for the other digits of the PIN number. Press the (Left) button to move back to adjust one of the previous digits.
 - When the (Tick) button is pressed after editing the final PIN digit, the PIN is checked for validity. If the number is not correct, the PIN must be re-entered.
 - If the PIN has been successfully entered (or the module PIN has not been enabled), the editor is displayed:
- Editor - Display

Contrast

53%

EDITING A PARAMETER

- Enter the editor as described above.
- Press the (Right) or (Left) buttons to cycle to the section to view/change.
- Press the (Up) or (Down) buttons to select the parameter to view/change within the currently selected section.
- To edit the parameter, press the (Tick) button to enter edit mode. The parameter begins to flash to indicate editing.
- Press the (Up) or (Down) buttons to change the parameter to the required value.
- Press the (Tick) button to save the value. The parameter ceases flashing to indicate that it has been saved.
- To exit the editor and save the changes, press and hold the (Tick) button.
- To exit the editor and not save the changes, press and hold the (Stop/Reset) button.

NOTE: If the editor is left inactive for the duration of the LCD Page Timer, it is automatically exited to ensure security.

NOTE: The PIN number is automatically reset when the editor is exited (manually or automatically) to ensure security.



NOTE: Comprehensive module configuration is possible using the DSE Configuration Suite PC Software, refer to DSE publication 057-243 DSE7310 MKII & DSE7320 MKII Configuration Suite PC Software Manual available from www.deepseaelectronics.com.

MAIN CONFIGURATION EDITOR PARAMETERS

NOTE: Depending upon module configuration, some values in the *Main & Running Configuration Editors* may not be available. For more information refer to DSE publication 057-243 *DSE7310 MKII & DSE7320 MKII Configuration Suite PC Software Manual* available from www.deepseaelectronics.com

| Section | Parameter As Shown On Display | Value | |
|---------------------------|--|--|--|
| Display | Contrast | 0 % | |
| | Language | English | |
| | Current Date and Time | dd:mm:yyyy, hh:mm:ss | |
| | Dual Mutual Mode | Set Priority / Run Time / Engine Hours | |
| | Dual Mutual Priority | 0 | |
| | Dual Mutual Duty Time | 0 h 0 m 0 s | |
| | Alt Config | Config To Edit | Main Configuration / Alt Config 1,2,3,4 or 5 |
| | | Default Configuration | Main Configuration / Alt Config 1,2,3,4 or 5 |
| Engine | Oil Pressure Low Shutdown | 0.00 bar 0 psi 0 kPa | |
| | Oil Pressure Low Pre Alarm | 0.00 bar 0 psi 0 kPa | |
| | Coolant Temperature Low Warning | 0 °C 0 °F | |
| | Coolant Temperature High Pre Alarm | 0 °C 0 °F | |
| | Coolant Temperature High Electrical Trip | 0 °C 0 °F | |
| | Coolant Temperature High Shutdown | 0 °C 0 °F | |
| | Fuel Usage Running Rate | 0 % | |
| | Fuel Usage Stopped Rate | 0 % | |
| | Specific Gravity | 0.00 | |
| | Pre Heat Temp | 0 °C 0 °F | |
| | Pre Heat Timer | 0 h 0 m 0 s | |
| | Post Heat Temp | 0 °C 0 °F | |
| | Post Heat Timer | 0 h 0 m 0 s | |
| | Droop Control | Active / Inactive | |
| | Droop Control | 0.0 % | |
| | Crank Disconnect Oil Pressure Delay | 0.0 s | |
| | Crank Disconnect | 0 V | |
| | Under Speed Shutdown | Active / Inactive | |
| | Under Speed Shutdown | 0 RPM | |
| | Under Speed Warning | Active / Inactive | |
| | Under Speed Warning | 0 RPM | |
| | Under Speed Delay | 0.0 s | |
| | Over Speed Warning | Active / Inactive | |
| | Over Speed Warning | 0 RPM | |
| | Over Speed Shutdown | 0 RPM | |
| | Over Speed Delay | 0.0 s | |
| | Overspeed Overshoot | 0 % | |
| | Overspeed Overshoot Delay | 0 m 0.0 s | |
| | Battery Under Voltage Warning | Active / Inactive | |
| | Battery Under Voltage Warning | 0.0 V | |
| | Battery Under Voltage Warning Delay | 0 h 0 m 0 s | |
| | Battery Over Voltage Warning | Active / Inactive | |
| | Battery Over Voltage Warning | 0.0 V | |
| | Battery Over Voltage Warning Delay | 0 h 0 m 0 s | |
| | Charge Alternator Failure Warning | Active / Inactive | |
| | Charge Alternator Failure Warning | 0.0 V | |
| | Charge Alternator Warning Delay | 0 h 0 m 0 s | |
| | Charge Alternator Failure Shutdown | Active / Inactive | |
| | Charge Alternator Failure Shutdown | 0.0 V | |
| | Charge Alternator Shutdown Delay | 0 h 0 m 0 s | |
| | Inlet Temperature Shutdown | 0 °C 0 °F | |
| | Inlet Temperature Pre-Alarm | 0 °C 0 °F | |
| | Generator | AC System | 3 Phase, 4 Wire |
| | | Under Voltage Shutdown | 0 V |
| | | Under Voltage Pre Alarm | 0 V |
| | | Under Voltage Delay | 0.0 s |
| | | Nominal Voltage | 0 V |
| Over Voltage Pre Alarm | | 0 V | |
| Over Voltage Shutdown | | 0 V | |
| Over Voltage Delay | | 0.0 s | |
| Under Frequency Shutdown | | 0.0 Hz | |
| Under Frequency Pre Alarm | | 0.0 Hz | |
| Under Frequency Delay | | 0.0 s | |

MAIN CONFIGURATION EDITOR PARAMETERS (CONTINUED)

| Section | Parameter As Shown On Display | Value | |
|--|-------------------------------|--|-------------------|
| Generator (Continued) | Nominal Frequency | 0.0 Hz | |
| | Over Frequency Pre Alarm | 0.0 Hz | |
| | Over Frequency Shutdown | 0.0 Hz | |
| | Over Frequency Delay | 0.0 s | |
| | Frequency Overshoot | 0 % | |
| | Frequency Overshoot Delay | 0.0 s | |
| | CT Primary | 0 A | |
| | CT Secondary | 0 A | |
| | Earth CT Primary | 0 A | |
| | Full Load Rating | 0 A | |
| | Delayed Over Current | Active / Inactive | |
| | Delayed Over Current | 0 % | |
| | Earth Fault Trip | Active / Inactive | |
| | Earth Fault Trip | 0 % | |
| | kW Overload Trip | 0 % | |
| | Mains DSE7320 MKII Only | AC System | 3 Phase, 4 Wire |
| | | Under Voltage Trip | 0 V |
| Over Voltage Trip | | 0 V | |
| Under Frequency Trip | | 0.0 Hz | |
| Over Frequency Trip | | 0.0 Hz | |
| Start Delay Off Load | | 0 h 0 m 0 s | |
| Start Delay On Load | | 0 h 0 m 0 s | |
| Start Delay Mains Fail | | 0 h 0 m 0 s | |
| Start Delay Telemetry | | 0 h 0 m 0 s | |
| Mains Transient Delay | | 0 m 0 s | |
| Timers | Engine Cranking | 0 m 0 s | |
| | Engine Cranking Rest | 0 m 0 s | |
| | Engine Smoke Limiting | 0 m 0 s | |
| | Engine Smoke Limiting Off | 0 m 0 s | |
| | Engine Safety On Delay | 0 m 0 s | |
| | Engine Warming | 0 h 0 m 0 s | |
| | ECU Override | 0 m 0 s | |
| | Mains Transfer Time | 0 m 0.0 s | |
| | Return Delay | 0 h 0 m 0 s | |
| | Engine Cooling | 0 h 0 m 0 s | |
| | Engine Fail To Stop Delay | 0 m 0 s | |
| | LCD Page Delay | 0 h 0 m 0 s | |
| | LCD Scroll Delay | 0 h 0 m 0 s | |
| | Sleep Timer | 0 h 0 m 0 s | |
| | Backlight Timer | 0 h 0 m 0 s | |
| | Schedule | Schedule | Active / Inactive |
| | | Schedule Bank 1 Period | Weekly / Monthly, |
| On Load / Off Load / Auto Start Inhibit, Week, Start Time, Run Time and Day Selection (1 to 8) | | Press Tick  to begin editing then up or down when selecting the different parameters in the scheduler. | |
| Schedule Bank 2 Period | | Weekly / Monthly, | |
| On Load / Off Load / Auto Start Inhibit, Week, Start Time, Run Time and Day Selection (1 to 8) | | Press Tick  to begin editing then up or down when selecting the different parameters in the scheduler. | |


DIMENSIONS AND MOUNTING

| Parameter | Specification |
|---|--|
| Dimensions | 245 mm x 184 mm x 51 mm (9.6" x 7.2" x 2.0") |
| Panel Cut-out | 220 mm x 160 mm (8.7" x 6.3") |
| Weight | 0.98 kg (2.16 lb) |
| Operating Temperature With Standard Display | -30 °C to +70 °C (-22 °F to +158 °F) |
| Operating Temperature With Heated Display | -40 °C to +70 °C (-40 °F to +158 °F) |
| Storage Temperature | -40 °C to +80 °C (-40 °F to +176 °F) |

ACCESSING THE 'RUNNING' CONFIGURATION EDITOR

- The 'running' editor can be entered while the engine is running. All protections remain active if the engine is running while the running editor is entered.



- Press and hold the  (Tick) button to enter the running editor.

RUNNING CONFIGURATION EDITOR PARAMETERS

| Section | Parameter As Shown On Display | Values |
|---------------------|---------------------------------|-----------------------|
| Display | Contrast | 0 % |
| | Language | English |
| | Dual Mutual Status | Set Priority (1 to 8) |
| Engine | Manual Frequency Trim | 0.0 Hz |
| | Speed Bias | 0.0 |
| | Governor Gain | 0 |
| | Frequency Adjust | 0.0 % |
| | DPF Auto Regen Inhibit | Active / Inactive |
| | DPF Manual Regeneration Request | Active / Inactive |
| AVR | ECU Service Mode | Active / Inactive |
| | Droop (% of Set Point) | 0.0 |
| | Proportional Set Point | 0.0 |
| | Integral Set Point | 0.0 |
| | Derivative Set Point | 0.0 |
| | Off Load Duty Cycle | 0.0 |
| | Maximum Duty Cycle | 0.0 |
| | Soft Start Ramp Start Point | 0.0 |
| | Soft Start Ramp Rate (%/Hz) | 0.0 |
| | Alternative Configuration | 0 |
| Stability Selection | 0 | |

REQUIREMENTS FOR UL CERTIFICATION

WARNING! More than one live circuit exists, see diagram overleaf for further information.

| Specification | Description |
|----------------------------------|---|
| Screw Terminal Tightening Torque | • 4.5 lb-in (0.5 Nm) |
| Conductors | <ul style="list-style-type: none"> Terminals suitable for connection of conductor size 13 AWG to 20 AWG (0.5 mm² to 2.5 mm²). Conductor protection must be provided in accordance with NFPA 70, Article 240 Low voltage circuits (35 V or less) must be supplied from the engine starting battery or an isolated secondary circuit. The communication, sensor, and/or battery derived circuit conductors shall be separated and secured to maintain at least 1/4" (6 mm) separation from the generator and mains connected circuit conductors unless all conductors are rated 600 V or greater. |
| Current Inputs | • Must be connected through UL Listed or Recognized isolating current transformers with the secondary rating of 5 A max. |
| Communication Circuits | • Must be connected to communication circuits of UL Listed equipment |
| DC Output Pilot Duty | • 0.5 A |
| Mounting | <ul style="list-style-type: none"> Suitable for flat surface mounting in Type 1 Enclosure Type rating with surrounding air temperature -22 °F to +122 °F (-30 °C to +50 °C) Suitable for pollution degree 3 environments when voltage sensing inputs do not exceed 300 V. When used to monitor voltages over 300 V device to be installed in an unventilated or filtered ventilation enclosure to maintain a pollution degree 2 environment. |
| Operating Temperature | • -22 °F to +122 °F (-30 °C to +50 °C) |